



付図 18 軌道パッド

(18.1) 5形50・9形50・10形50・F1形50用

(18.2) 5形60・9形60・F1形60用



(18.3) 10形40用

(18.4) 102形7用

